

Official Copy

Nov 21, 1997 - 13 made
Apr. 14/98 - 10 "

Date Purchased _____ Machine Serial No. _____

Size Of Spreader _____ Options _____

Please Note:

The Key Number System In This Parts Book Is Arranged As Follows:

- 0 -- Key Number With One Circle Denotes Main Assemblies
- Key Numbers Not Circled Are Individual Parts.

Please Order Parts By Number


**MODEL "E" TRUCK MOUNT
12000, 14000, 15000, 18000 LITRE
LIQUID MANURE SPREADER**

Operating And Safety Instruction:

1. After using spreader in freezing conditions make sure impeller housing is drained.
2. Wash tank inside and out each time work is finished. This will increase life of tank by many years.
3. Much of the fertilizer value of manure is lost when exposed to air. Getting the manure covered quickly is a very important part of spreading manure.
4. If rustproof coating on interior shows signs of deterioration, have interior repainted. This can be done with a roller or brush. This helps to increase the life of your spreader. It is a valuable maintenance procedure.
5. Make sure all moving parts are shielded to prevent coming in contact with loose clothing.
6. Never enter a tanker without special breathing equipment to supply oxygen. Manure gases can kill instantly. One breath of Hydrogen Sulphide can kill.

18000 L TM "E" TANK

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	386-01-00-000	18000 L "E" Tank.Sill & Funnel Assy	1
2	340-01-01-000	18000 L Tank Assy	1
3	316-22-00-000	Hold Down Bracket Assy	4
4	316-24-00-000	Hold Down Assy	4
5	364-47-00-000	Short Safety Bar Assy	2
6	364-49-00-000	Long Safety Bar Assy	1
7	340-01-01-300	Tank End	2
8	340-01-01-301	Tank Shell	3




18000 L TM "E" TANK CONTINUED

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
9	340-01-01-302	Baffle	2
10	340-01-06-312	Tank End Stiffener	2
11	340-01-06-464	Stiffener Cap	4
12	340-01-01-557	Baffle Reinforcing Angle	4
13	315-30-09-100	Drain Pipe	1
14	364-02-00-008	Ladder Rung	4
15	364-02-00-006	Manhole	1
16	300-01-00-012	Lift Hook	7
17	340-01-00-546	Reinforcing Plate	3
18	386-01-00-001	Vertical Reinforcing Channel	4
19	340-00-00-515	Sill	2
20	340-00-00-516	Sill Cap	4
21	330-66-00-258	Stiffener Caps	4
22	340-01-00-498	Serial Number Plate	1
23	316-22-00-012	Hold Down Angle Bracket	4
24	316-22-00-035	Hold Down Angle Gusset	8
25	316-24-00-044	Bracket Main Piece	4
26	316-24-00-045	Spacer Bar	4
27	316-24-00-046	Hold Down Return	4
28	316-24-00-047	Gusset	8
29	364-00-00-155	Short Manhole Safety Bar	2
30	364-49-00-164	Long Manhole Safety Bar	1
31	340-62-00-000	Husky Flag Kit	1
32	340-00-00-536	Flag Spring Holder	1
33	R08152	#6 X 1/4" Pan Head Screw	2
34	R07663	1" X 3" Hex Head Bolt	2
35	R07882	1" Hex Lock Nut	4
36	R07669	1" X 8" Hex Hd Bolt	2
37	R08034	Hp88 1 X 4 Hold Down Spring	2
38	R09512	"Capacity" Decal	1
39	R09784	"Danger Toxic Gas" Decal	1
40	R09509	"Made In Canada" Decal	1
41	R09510	"Husky" Decal	2
42	R09511	Accent Strips	2
43	R09071	Serial Number	1
44	R07825	1/2" Flat Washer	3
45	R08207	3/32 X 1 1/2" S.S. Cotter Pin	3
46	340-62-00-553	Indicator	1
47	R008163	Clip	1
48	R08037	Flag Spring	1
49	R07926	5/16 - 18 X 1/4" S.S. Set Screw	1
50	R07803	3/8 Lock Washer	4
51	R02286	3" Abs Plug	1
52	364-95-00-000	Ladder Assy	1
53	364-95-00-324	Ladder Step	6
54	364-95-00-325	Ladder Side	2
55	364-95-00-326	Ladder Lug	2
56	364-95-00-327	Ladder Tank Lug	6
57	R07620	3/8 X 1 1/2 Hex Bolt	4
58	R07783	3/8 Hex Nut	4

15000L TM 'E' TANK

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	385-01-00-000	15000 L Tank,Sill & Funnel Assy	1
2	335-01-01-000	15000 L Tank Assy	1
3	364-47-00-000	Short Safety Bar Assy	2
4	364-49-00-000	Long Safety Bar Assy	1
5	340-62-00-000	Husky Flag Kit	1
6	316-22-00-000	Hold Down Bracket Assy	4
7	316-24-00-000	Hold Down Assy	4
8	335-01-01-002	15000 L Tank Shell	3




15000 L TM "E" TANK CONTINUED

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
9	330-66-21-254	15000 L Tank End	2
10	330-66-00-257	Tank Stiffener	2
11	330-66-00-258	Stiffener Caps	8
12	300-01-00-012	Lift Hook	7
13	364-02-00-006	Manhole	1
14	333-26-00-049	Sills	2
15	332-11-00-026	Sill Caps	4
16	332-11-00-051	Vertical Reinforcing Channel	4
17	364-02-00-008	Ladder Rung	3
18	330-66-21-256	Baffle	1
19	330-66-21-570	Baffle Reinforcing Angle	2
20	340-62-00-553	Indicator	1
21	364-47-00-155	Manhole Safety Bar	2
22	364-49-00-164	Long Safety Bar	1
23	340-00-00-536	Flag Spring Holder	1
24	340-01-00-498	Serial Number Plate	1
25	316-22-00-012	Hold Down Angle Bracket	4
26	316-22-00-035	Hold Down Angle Gusset	8
27	316-24-00-044	Bracket Main Pc	4
28	316-24-00-045	Spacer Bar	4
29	316-24-00-046	Hold Down Return	4
30	316-24-00-047	Gusset	8
31	315-30-09-100	Drain Pipe	1
32	R08207	3/32 X 1 1/2" S.S. Cotter Pin	3
33	R09071	Serial Number	1
34	R08152	#6 X 1/4" Pan Head Screw	2
35	R07663	1" X 3" Hex Hd Bolt	2
36	R07882	1" Hex Lock Nut	4
37	R07669	1" X 6" Hex Hd Bolt	2
38	R08034	Hp88 1 X 4" Hold Down Spring	2
39	R09509	"Made In Canada" Decal	1
40	R09512	"Capacity" Decal	1
41	R09784	"Danger Toxic Gas" Decal	1
42	R09510	"Husky" Decal	2
43	R09511	Accent Strip	2
44	R07783	3/8 Hex Nut	4
45	R08037	Flag Spring	1
46	R08163	Clip	2
47	R07926	5/16 - 18 X 1/4" S.S. Set Screw	1
48	R07803	3/8 Lock Washer	4
49	R07825	1/2" Flat Washer	3
50	R02286	3" Abs Plug	1
51	364-95-00-000	Ladder Assy	1
52	364-95-00-324	Ladder Step	6
53	364-95-00-325	Ladder Side	2
54	364-95-00-326	Ladder Lug	2
55	364-95-00-327	Ladder - Tank Lug	6
56	R07620	3/8 X 1 1/2 Hex Bolt	4

14000L TM 'E' TANK

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	384-01-00-000	14000 L Tank, Sill & Funnel Assy	1
2	330-66-21-000	14000 L Tank Assy	1
3	364-47-00-000	Short Safety Bar Assy	2
4	364-49-00-000	Long Safety Bar Assy	1
5	340-62-00-000	Husky Flag Kit	1
6	316-22-00-000	Hold Down Bracket Assy	4
7	316-24-00-000	Hold Down Assy	4
8	330-66-21-255	14000 L Tank Shell	3




14000 L TM "E" TANK CONTINUED

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
9	330-66-21-254	14000 L Tank End	2
10	330-66-00-257	Tank Stiffener	2
11	330-66-00-258	Stiffener Caps	8
12	300-01-00-012	Lift Hook	7
13	364-02-00-006	Manhole	1
14	232-11-00-025	Sills	2
15	332-11-00-026	Sill Caps	4
16	332-11-00-051	Vertical Reinforcing Channel	4
17	364-02-00-008	Ladder Rung	3
18	330-66-21-256	Baffle	1
19	330-66-21-570	Baffle Reinforcing Angle	2
20	340-62-00-553	Indicator	1
21	364-47-00-155	Manhole Safety Bar	2
22	364-49-00-164	Long Safety Bar	1
23	340-00-00-536	Flag Spring Holder	1
24	340-01-00-498	Serial Number Plate	1
25	316-22-00-012	Hold Down Angle Bracket	4
26	316-22-00-035	Hold Down Angle Gusset	8
27	316-24-00-044	Bracket Main Pc	4
28	316-24-00-045	Spacer Bar	4
29	316-24-00-046	Hold Down Return	4
30	316-24-00-047	Gusset	8
31	315-30-09-100	Drain Pipe	1
32	R08207	3/32 X 1 1/2" S.S. Cotter Pin	3
33	R09071	Serial Number	1
34	R08152	#6 X 1/4" Pan Head Screw	2
35	R07663	1" X 3" Hex Hd Bolt	2
36	R07882	1" Hex Lock Nut	4
37	R07669	1" X 6" Hex Hd Bolt	2
38	R08034	Hp88 1 X 4" Hold Down Spring	2
39	R09509	"Made In Canada" Decal	1
40	R09512	"Capacity" Decal	1
41	R09784	"Danger Toxic Gas" Decal	1
42	R09510	"Husky" Decal	2
43	R09511	Accent Strip	2
44	R07783	3/8 Hex Nut	4
45	R08037	Flag Spring	1
46	R08063	Clip	2
47	R07926	5/16 - 18 X 1/4" S.S. Set Screw	1
48	R07803	3/8 Lock Washer	4
49	R07825	1/2" Flat Washer	3
50	R02286	3" Abs Plug	1
51	364-95-00-000	Ladder Assy	1
52	364-95-00-324	Ladder Step	6
53	364-95-00-325	Ladder Side	2
54	364-95-00-326	Ladder Lug	2
55	364-96-00-327	Ladder - Tank Lug	6
56	R07620	3/8 X 1 1/2 Hex Bolt	4

12000L TM 'E' TANK

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	383-01-00-000	12000L Tank, Sill & Funnel Assy.	1
2	326-88-25-000	12000L Tank Assy.	1
3	364-47-00-000	Short Safety Bar Assy.	2
4	364-49-00-000	Long Safety Bar Assy.	1
5	340-62-00-000	Husky Flag Kit	1
6	316-22-00-000	Hold Down Bracket Assy.	4
7	316-24-00-000	Hold Down Assy.	4
8	326-88-25-278	12000L Tank Shell	3



12000L TM 'E' TANK CONTINUED


<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
9	326-88-25-277	12000L Tank End	2
10	326-88-00-280	Tank Stiffener	2
11	330-66-00-258	Stiffener Caps	8
12	330-01-00-012	Lift Hook	7
13	364-02-00-006	Manhole	1
14	327-15-00-027	Sills	2
15	327-15-00-028	Sill Caps	4
16	327-15-00-050	Vertical Reinforcing Channel	4
17	364-02-00-008	Ladder Rung	7
18	326-88-25-279	Baffle	1
19	326-88-25-571	Baffle Reinforcing Angle	2
20	340-62-00-553	Indicator	1
21	364-47-00-155	Manhole Safety Bar	2
22	364-49-00-164	Long Safety Bar	1
23	340-00-00-536	Flag Spring Holder	1
24	340-01-00-498	Serial Number Plate	1
25	316-22-00-012	Hold Down Angle Bracket	4
26	316-22-00-035	Hold Down Angle Gusset	8
27	316-24-00-044	Bracket Main Pc	4
28	316-24-00-045	Spacer Bar	4
29	316-24-00-046	Hold Down Return	4
30	316-24-00-047	Gusset	8
31	315-30-09-100	Drain Pipe	1
32	R08207	3/32 X 1 1/2" Ss Cotter Pin	3
33	R09071	Serial Number	1
34	R08152	#6 X 1/4" Pan Head Screw	2
35	R07663	1" X 3" Hex Hd Bolt	2
36	R07882	1" Nex Lock Nut	4
37	R07669	1" X 6" Hex Hd Bolt	2
38	R08034	Hp88 1 X 4" Hold Down Spring	2
39	R09509	"Made In Canada" Decal	1
40	R09512	"Capacity" Decal	1
41	R09784	"Danger Toxic Gas" Decal	1
42	R09510	"Husky" Decal	2
43	R09511	Accent Strip	2
44	R07783	3/8 Hex Nut	4
45	R08037	Flag Spring	1
46	R08063	Clip	2
47	R07926	5/16 - 18 X 1/4" Ss Set Screw	1
48	R07803	3/8 Lock Washer	4
49	R07825	1/2" Flat Washer	3
50	R02286	3" Abs Plug	1
51	364-95-00-000	Ladder Assy.	1
52	364-95-00-324	Ladder Step	6
53	364-95-00-325	Ladder Side	2
54	364-95-00-326	Ladder Lug	2
55	364-95-00-327	Ladder - Tank Lug	6
56	R07620	3/8 X 1 1/2 Hex Bolt	4

FAN & HOUSING KIT

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	364-23-00-000	Model E Fan & Housing Kit 540 Rpm	*
	364-56-00-000	Model E Fan & Housing Kit 1000 Rpm	1
2	364-65-00-000	540 Fan, Cover Plate. & Brg Kit	*
	364-66-00-000	1000 Fan, Cover Plate. & Brg Kit	1
3	364-01-03-000	Fan Housing Assembly	1
4	364-01-15-000	Housing Back Plate Assembly	1
5	364-41-00-000	Pto Holder Assembly	1
6	364-62-00-000	Drain Plug Kit	1
7	364-67-00-000	Cover Plate Assembly	1
8	364-61-00-000	Bearing Holder Assembly	1
9	364-72-00-000	Fan, Shaft & Agitator Assy - 540	*
	364-73-00-000	Fan, Shaft & Agitator Assy -1000	1
10	364-01-03-018	Housing Band	1
11	364-01-03-019	Housing Flange	1
12	364-01-03-376	Discharge Ring - 6"	2
13	364-01-03-063	Discharge Tube	1
14	364-01-03-081	Fan Housing Vertical Pc	1
15	364-01-03-103	Outlet Side Pc	2
16	364-01-03-104	Outlet Top Pc	1
17	364-01-03-105	Outlet Bottom Pc	1
18	364-01-03-106	Housing Back Plate	1
19	364-01-03-156	Housing Band Aid	1
20	364-41-00-132	Pto Holder	1
21	364-41-00-133	Pto Holder Brkt	1
22	364-00-00-029	Flip Guard	1
23	364-67-00-211	Cover Plate	1
24	364-61-00-191	Brg Tube	1
25	364-61-00-192	Seal Tube Back Plate	1
26	364-61-00-193	Seal Tube Gusset	2
27	364-61-00-197	RH Flip Guard Brkt	1
28	364-61-00-198	LH Flip Guard Brkt	1
29	364-00-00-332	Seal Tube Cap	1
30	364-63-00-209	Impeller Back Plate	1
31	364-63-00-208	540 Rpm Fan Blade	*
	364-64-00-210	1000 Rpm Fan Blade	4
32	364-03-00-024	Gusset	4
33	364-72-00-226	Fan Shaft	1
34	364-72-00-227	Agitator Blades	3
35	364-31-00-000	Hose Tube Assy - 6"	1
36	358-92-01-00	Hose Tube Assy - 8"	1
37	364-00-00-212	Stake Nut	1
38	R07619	3/8 X 1 Hex Bolt	7
39	R07886	3/8 Lock Nut	2
40	R07671	7/16 X 1 1/4 Hex Bolt	8
41	R07784	7/16 Hex Nut	8
42	R07804	7/16 Lock Washer	8
43	R21197	Seal - 2 1/2 X 3 X 1/4	2
44	R20115	Cone	2


FAN & HOUSING KIT CONTINUED

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
45	R20113	Cup	2
46	R21196	Seal - 1.5 X 2.835 X .313	1
47	R07879	7/16 Flange Nut	4
48	R08188	1/4 " Npt Grease Fitting	1
49	R08175	5/16-18 Unc X 1 3/4 Cap Screw	2
50	R09785	"Danger" Decal	1
51	R07774	7/16 X 1 1/4 Carriage Bolt Gr. 5 Black	4
52	R04100	Silicone Sealant	1
53	R20238	Hardened Sleeve	1
54	358-92-01-301	Discharge Ring - 8"	1
55	358-92-01-302	Discharge Tube	1
56	R07803	3/8 Lock Washer	5
57	R07783	3/8 Hex Nut	5
58	364-61-01-000	Brg Holder Assembly With Cups	1




DISCHARGE PIPE ASSEMBLY

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	364-19-00-000	Discharge Pipe Assembly - 14000L	1
	359-30-00-000	Discharge Pipe Assembly - 15000L	1
	362-59-00-000	Discharge Pipe Assembly - 9000L & 12000L	1
	362-20-00-000	Discharge Pipe Assembly - 7000L	1
2	364-25-00-000	Discharge Pipe End Section	1
3	364-68-00-000	Splash Plate Assembly	1
4	364-19-00-065	Horizontal Discharge Pipe - 9, 12, & 14000L	1
	359-30-00-108	Horizontal Discharge Pipe - 15000L	1
5	362-20-00-068	Horizontal Discharge Pipe - 7000L	1
	364-19-00-064	Vertical Discharge Pipe 14, & 15000L	1
	364-20-00-184	Vertical Discharge Pipe 7, 9 & 12000L	1
6	364-19-00-082	Discharge Pipe Corner Piece	2
7	364-25-00-088	Discharge Pipe Flange Piece	1
8	364-25-00-067	Discharge Pipe End Piece	1
9	364-19-00-087	Discharge Pipe Flange	2
10	364-21-00-069	Splash Plate	1
11	364-68-00-215	Clamping Tube	1
12	364-21-00-071	Clamping Tube Bracket	2
13	364-00-00-083	Discharge Clamp Upper Piece	2
14	364-50-00-084	Discharge Clamp Base Piece	2
15	364-00-00-066	Flex Hose	1
16	R02482	6" Clamp	2
17	R07622	3/8 X 2 1/2 Hex Bolt	2
18	R07675	3/8 X 1 1/4 Hex Bolt	4
19	R07783	3/8 Hex Nut	6
20	R07803	3/8 Lock Washer	6
21	364-50-00-000	Discharge Clamp Base Assy.	2
22	364-50-00-165	Discharge Clamp Spacer	2
23	364-21-00-224	Splash Plate Wing	2
24	R07671	7/16 X 1 1/4 Hex Bolt	6
25	R07784	7/16 Hex Nut	6
26	R07804	7/16 Lock Washer	6



18000L DISCHARGE PIPE ASSEMBLY


<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	358-32-00-000	Discharge Pipe Assy - 18000L	1
2	364-25-00-000	Discharge Pipe End Section	1
3	364-68-00-000	Splash Plate Assy.	1
4	357-16-00-000	6" Discharge Pipe & Holder	2
5	357-16-01-000	Base Holder Assy.	2
6	357-16-02-000	Pipe Holder Assy	2
7	359-30-00-108	18000L Discharge Pipe - 6"	1
8	364-19-00-082	Discharge Pipe Corner Piece	2
9	358-32-00-109	Vertical Discharge Pipe	1
10	364-19-00-087	Flange	2
11	364-25-00-088	Discharge Pipe Flange Piece	1
12	364-25-00-067	Discharge Pipe End Piece	1
13	364-68-00-215	Clamping Tube	1
14	364-21-00-071	Clamping Tube Bracket	2
15	364-21-00-069	Splash Plate	1
16	364-21-00-224	Splash Plate Wing	2
17	357-16-01-130	Base Plate	2
18	357-16-01-131	Stub	2
19	357-16-00-133	Pipe Holder - 6"	4
20	357-16-02-137	Upper Stub	2
21	364-00-00-066	Flex Hose	1
22	R07671	7/16 X 1 1/4 Hex Bolt	6
23	R07784	7/16 Hex Nut	6
24	R07804	7/16 Lock Washer	6
25	R07622	3/8 X 2 1/2 Hex Bolt	4
26	R07620	3/8 X 1 1/2 Hex Bolt	4
27	R07783	3/8 Hex Nuts	8
28	R07803	3/8" Lock Washer	8
29	R02482	6" Clamps	2



DRAIN PLUG KIT


<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	364-62-01-000	Drain Plug Sleeve Assy	1
2	364-62-04-000	Plug Assy	1
3	364-62-03-000	Handle Assy	1
4	364-62-00-199	Housing Brkt	2
5	364-62-01-200	Sleeve Linkage	1
6	364-62-01-201	Sleeve	1
7	364-62-02-202	Adjustment Rod	1
8	364-62-02-203	Plug Plate	1
9	364-62-02-204	Plug Rubber	1
10	364-62-00-205	Short Linkage	1
11	364-62-03-206	Lh Handle	1
12	364-62-03-207	Rh Handle	1
13	364-01-03-110	Drain Pipe	1
14	R08176	1/4-20 Unc X 7/8 Short Thrd Bolt	4
15	R08048	1/4-20 Lock Nut	4
16	R07885	1/2-13 Unc Hex Nyloc Nut	1
17	R08046	1/2-13 Unc Jam Nut	3
18	364-62-04-370	Plug Washer	1


DRAIN PLUG KIT
364-62-00-000



SITE GAUGE KIT

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	330-20-01-000	Float Arm Assy	1
2	330-20-02-000	Indicator Arm Assy	1
3	330-20-03-000	Access Tube Assy	1
4	330-20-04-000	Cover Plate Assy	1
5	330-20-01-551	Float Arm	1
6	330-20-01-552	Float Straps	2
7	330-93-00-375	Float	1
8	330-20-04-562	Bronze Bearing Holder	1
9	330-20-02-553	Indicator Arm Hub	1
10	330-20-02-554	Indicator Arm	1
11	330-20-03-556	Access Tube	1
12	330-20-03-560	Access Tube Flange	1
13	330-20-00-557	Cover Plate	1
14	R20865	1/2 X 5/8 X 1/16" O Ring	1
15	R09529	"Full" Decal	1
16	R09530	"Empty" Decal	1
17	R07974	External Retaining Ring	2
18	R21173	1/2 X 5/8 X 1/2" Bronze Bushing	3
19	R08241	3/16 X 1 Stainless Steel Roll Pin	1
20	R07675	3/8 X 1 1/4" Hex Bolt	6
21	R07783	3/8" Hex Nut	6
22	R07803	3/8" Lock Washer	6
23	R08207	5/32 X 1 1/2" Ss Cotter Pin	1






'E' TM DIRECT HYD. DRIVE KIT

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	384-02-01-000	Direct Drive Mount Plate Assy.	1
2	384-02-00-076	#60 - 18 Sprocket W/6T Spline	1
3	384-02-03-000	Case Drain Hyd. Hose Assy.	1
4	364-48-24-000	Hydraulic Hose Assy.	2
5	351-03-00-000	Hydraulic Hose Assy.	2
6	384-02-01-002	R.H. Extension Plate	1
7	384-02-01-003	L.H. Extension Plate	1
8	384-02-01-004	Motor Mount Plate	1
9	384-02-00-005	Guard	1
10	384-02-01-012	Reinforcing Strap	1
11	R02146	1/2" Plastic Pipe Plug	1
12	364-48-23-162	Spline Adaptor	1
13	384-02-00-008	Hydraulic Hose Clamp	1
14	364-48-24-163	Hydraulic Hose 3/4"	2
15	351-03-00-004	Hydraulic Hose 3/4	2
16	384-02-00-009	3/4" Hydraulic Pipe	2
17	384-02-00-010	1/2" Hydraulic Pipe	1
18	351-00-00-009	Hydraulic Pipe Fastener	4
19	384-02-03-011	1/4" Hydraulic Hose	1
20	R20617	#60-18 Coupling Cover	1
21	R20883	#60 Coupling Chain W/Conn Link	1
22	R21308	7/16 Sae X 1/4 Npt X 45 Deg. Adaptor	1
23	R20802	1/4" Npt Male Stem	1
24	R21231	Ferrule	2
25	R20803	3/8 Npt Male Stem	1
26	R02043	1/2 - 3/8 Bushing	1
27	R02059	1/2" Pipe Coupling	2
28	R21104	Pipe Clip	4
29	R21422	Ms160 Hydraulic Motor W/Key	1
30	R21401	3/4" Hydraulic Coupling	4
31	R21406	3/4" Plastic Plug	2
32	R21241	3/4" Male Stem	8
33	R20824	3/4" Ferrule	8
34	R21393	3/4 Npt Hydraulic Swivel Tee	2
35	R21202	3/4" Npt In Line Check Valve	1
36	R21332	3/4" Npt 90 Deg. Swivel Adaptor	2
37	R20815	7/8 Sae X 3/4" Npt Straight Swivel	2
38	R07911	3/8 X 3/4 Set Screw	4
39	R07744	1/2 X 2 Carriage Bolt	4
40	R07785	1/2" Hex Nut	4
41	R07805	1/2" Lock Washer	4
42	R07620	3/8 X 1 1/2 Hex Bolt	4
43	R08247	3/8" Nyloc Hex Nut	5
44	R07725	3/8 X 2 1/2" Hex Bolt	1
45	R07698	1/4 X 1/2 Hex Bolt	6
46	R07781	1/4" Hex Nut	4
47	R07801	1/4 Lock Washer	2

MATERIALS NOT SHOWN

- RO4046 16 GA ELECTRICAL WIRE
- RO4043 16-3 CABTIRE CABLE
- R10094 1/4" SHRINK TUBE
- RO7698 1/4 X 1/2" CLIP BOLTS

THIS SIDE SHOWN
W/O LIGHTS



ACCESSORIES

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>	
1	332-27-00-000	Taper Fender Kit-No Lights-8 Ft O A 14000 & 15000L	1	
	327-29-00-000	Taper Fender Kit-No Lights-8Ft O A 12000L		
	386-02-00-000	Taper Fender Kit-No Lights-8' 6" O A 18000 & 23000L		
2	332-31-00-000	Taper Fender Kit W/Lights-8Ft O A 14000 & 15000L	1	
	327-32-00-000	Taper Fender Kit W/Lights-8 Ft OA 12000L		
	386-03-00-000	Taper Fender Kit W/Lights-8' 6" O A 18000 & 23000L		
3	332-27-00-069	14000L & 15000L Fender End-No Lights R.H 8 Ft. OA	1	
	332-27-00-070	14000L & 15000L Fender End-No Lights L.H 8Ft O A	1	
	327-29-00-076	12000L Fender End-No Lights Rh 8Ft O A	1	
	327-29-00-077	12000L Fender End-No Lights LH 8Ft OA	1	
	386-02-00-013	18000L & 23000L Fender Ends-No Lights Rh 8' 6" O A	1	
	386-02-00-014	18 & 23000L Fender Ends-No Lights L.H 8' 6"O A	1	
4	332-27-00-054	14000 & 15000L Fender-8Ft OA	1	
	327-29-00-061	12000L Fender-8 Ft O A	1	
5	386-02-00-015	18000L & 23000L Fender-8' 6" O A	1	
	332-31-00-071	R H Fender End W/Lights-8Ft O A 14000 & 15000L	1	
	332-31-00-072	LH Fender End W/Lights-8Ft OA 14000 & 15000L	1	
	327-32-00-074	Rh Fender End W/Lights-8Ft O A 12000L	1	
	327-32-00-075	Lh Fender End W/Lights-8Ft O A 12000L	1	
	386-03-00-016	R H Fender End W/Lights-8' 6" O A 18 & 23000L	1	
6	386-03-00-017	LH Fender End W/Lights-8' 6" OA 18 & 23000L	1	
	332-27-00-056	14000 & 15000L Front End Plate L H	1	
7	332-27-00-053	14000 & 15000L Front End Plate R H	1	
	327-29-00-062	12000L Front End Plate R H	1	
	327-29-00-063	12000L Front End Plate LH	1	
	386-02-00-018	18000 & 23000L Front End Plate R H	1	
	386-02-00-019	18000 & 23000L Front End Plate L H	1	
	332-27-00-055	14000 & 15000L Fender Gusset	2	
	327-29-00-064	12000L Fender Gusset	2	
	386-02-00-020	18000 & 23000L Fender Gusset	2	
	8	332-31-00-073	Inside Light Cover	2
	9	372-00-00-032	Mudflap Clamp Strap	2
10	372-00-00-045	Sticker Plate	1	
11	372-00-00-046	Sticker Plate Bracket	2	
12	R09528	Mud Flap	2	
13	R10192	Aluminium Junction Box W/Lid	1	
14	R10194	Water Tight Connectors	-	
15	R04060	1/2" Plastic Tube	-	
16	R21082	Hose Clips	-	
17	R10091	3 Cluster Clearance Light	1	
18	R10093	Licence Plate Light	1	
19	R10087	4" Stop & Tail Light	4	
20	R10088	4" Clear Backup Light	2	
21	R10089	Red Clearance Light	2	
22	R10090	Amber Clearance Light	2	
21	R09502	Husky Decal		
22	R10361	Reflective Tape		

ELECTRIC HYDRAULIC UNIT

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	R21424	M-130 1 Valve Electric/Hydraulic Unit	1
	R21427	M-380 2 Valve Electric/Hydraulic Unit	*
2	R04056	4 Ga. Battery Cable-Live	3M
3	R04056	4 Ga. Battery Cable-Ground	1M
4	R04063	Copper Wire End For Cable	4
5	R21334	1/4" M X 3/8 F 90 Sw Fitting	2
6	R11114	Hydraulic Hoses - As Needed	-

272-10-00-000 ELECTRIC HYDRAULIC UNIT

